### Class 16

# Photographic, cinematographic and optical apparatus

### Note(s)

Not including lamps for photography or filming (Cl. 26-05).

16-01 PHOTOGRAPHIC CAMERAS AND FILM CAMERAS	
ID No.	Indication
102824	Camcorders
102818	Cinematographic cameras
104788	Dashboard cameras
102819	Diaphragms [photography]
102820	Filming apparatus
104887	Photo booths
102821	Photographic cameras
102823	Shutters [photography]
102826	Surveillance cameras
102822	Television cameras
104886	Thermal imaging cameras
102827	Webcams

16-02 PROJECTORS AND VIEWERS	
ID No.	Indication
102829	Film projectors
102832	Overhead projectors
102828	Slide projectors  Diapositive projection apparatus
105003	Smart projectors
102830	Viewers for films
102831	Viewers for slides

#### 16-03 PHOTOCOPYING APPARATUS AND ENLARGERS

#### Note(s)

- a. Note(s)
- b. Including microfilming equipment and apparatus for viewing microfilms, as well as office machines known as "photocopying" apparatus which use other than photographic processes (in particular, thermal or magnetic processes).

ID No.	Indication
102835	Blueprint apparatus
102834	Easels for photographic enlarging
102833	Enlargers [photography]
102836	Microfilm reading apparatus
102838	Microfilming apparatus
102839	Photocopying apparatus
102840	Printers [photography]
102841	Toner cartridges for office copying apparatus

16-04 DEVELOPING APPARATUS AND EQUIPMENT	
ID No.	Indication
102845	Developing baths [containers] for photography
102843	Developing equipment for photographic prints
102842	Film developing apparatus and implements
102844	Tanks for developing films

#### 16-05 ACCESSORIES

#### Note(s)

- a. Note(s)
- b. Including filters for photographic cameras, exposure meters, tripods and photographic flash apparatus.

ID No.	Indication
104573	Ball heads for tripods [photography]
104789	Battery pack grips for photographic cameras
102851	Cardboard frames for photographs

102867	Cassettes for microfilms
102854	Diapositive loaders
102846	Exposure meters
102868	Exposure tables [photography]
102852	Film cassettes
102853	Film loaders [photography]
102857	Film splicers
102870	Films
102860	Filters [photography]
102861	Flashlamps for photography Flash apparatus [photography]
102850	Frames for transparencies [slides] Slide frames [photography]
102855	Holders for diapositives
102856	Mounting corners for photographs
102847	Photo reels
102862	Photometers [photography]
102849	Printing masks [photography]
102866	Projection screens
102858	Remote controls [except wireless] for diapositive projectors
102859	Shutter releases [photography]
102848	Spools for film projectors
102863	Stands for photographic or cinematographic cameras
102864	Titlers for films
102865	Tripods for cameras [photography]
102869	Viewfinders [photography]

#### 16-06 OPTICAL ARTICLES

### Note(s)

- a. Note(s)
- b. Including spectacles and microscopes.

c. Not including measuring instruments embodying optical devices (Cl. 10-04).

ID No.	Indication
102871	Anti-dazzle spectacles
102873	Arms of spectacle frames
102875	Binoculars Field glasses
102872	Bridges for spectacle frames
104793	Camera lens caps
104794	Camera lens hoods
104792	Camera lenses
102887	Combination of lenses
104791	Contact lenses
102899	Fastenings for spectacles
102882	Goggles
102897	Gun sights
102874	Hinges for spectacles
104618	Holders for telescopic sights
104795	Lenses for smartphone cameras
102877	Lenses, simple
102879	Magnifying glasses
102884	Microscopes
102894	Mirrors [optics]
102886	Monocles
102876	Opera glasses
102885	Peepholes for doors Judas-holes Spy-holes for doors
102889	Periscopes
102890	Pince-nez Lorgnettes
102893	Prisms [optics]

102891	Refractors
104796	Ski goggles
104790	Smartglasses
102896	Spectacle frames
102898	Spectacle lenses
102880	Spectacles
102881	Spyglasses
102892	Stereoscopes
102895	Sunglasses
104797	Swimming goggles
102878	Telescopes
102883	Telescopic sights for firearms

16-99 MISCELLANEOUS	
ID No.	Indication
102900	Microscope slides